

Vino Series Post System with Vertical Extension

Installation guide for Vino Series Post with FCP-2EX Brackets




3D INTERACTIVE INSTRUCTIONS

USE BILT TO ASSEMBLE WITH CONFIDENCE

For fast 3D step-by-step instructions,
download the free BILT app!



Available on most iOS and Android Devices



BILT.
Intelligent Instructions

Included:

- (1) Vertical Extension Bracket
- (1) Drill Bit
- (2) Self Drilling Screws

Additional Components:

(sold separately)

- (1) 62" Post Bottom (c-Channel)
- (1) 62" Post Top
- (1) Post (Top or Bottom)*
- 96 Mounting Plate screws
- Vino Series Post Mounting Plates with Self-Drilling Screws
- Vino Pins or Vino Rails

Required Tools:

- Drill
- Phillips head drill bit
- Phillips head screwdriver
- Level
- Pencil or Marker
- Tape measure
- Metal cutting saw
- Metal file
- Square
- Rubber Mallet (optional)

Important Note:

These installation instructions will assist you with installing the VintageView Vino Series Post System with Vertical Extension Bracket to allow for an installation height of up to 182 (4,623mm). The Post with Extension creates a 2" (51 mm) standoff from the wall.

* If using a Post Bottom (c-channel piece) as the third section, you must cut at least 8" (204mm) below the visible c-channel to ensure welded section (hidden) is removed. This will leave 54" (1372mm) of usable section.

Fasteners:

Fasteners for securing Mounting Plates to the Vino Series Posts are provided (self-drilling screws). Each mounting Plate is pre-drilled for installing Post. When installing finished Vino Series Post to the floor or ceiling, please use the following recommendations for fasteners:

Guidelines for Floor/Ceiling Hardware

Wood/Stud: #8 x 1-1/4" course thread screws (or longer)

Concrete, Brick, or Stucco: 3/16" x 1-1/4" masonry screw
or #8 x 1- 1/4" screw with appropriate size expanding anchor

Drywall: Expanding hollow wall anchors with at least #8 screw size






Figure A




Figure B




Figure C



Figure D




Figure E

1. IDENTIFY PROPER HARDWARE

Using the chart on the previous page, identify the proper floor/ceiling hardware (not included) that will be needed for your specific project. For drywall surfaces in floor or ceiling, VintageView recommend installing to joists or wood backing when available.

2. MEASURE

Measure the desired location's ceiling height.

3. INSERT VERTICAL EXTENSION BRACKET

Insert the Vertical Extension Bracket into the Post Top (Figure A). A Rubber Mallet may be needed to connect fully.

4. SECURE THE BRACKET

Using the provided Drill Bit, drill through Post and Mount below the connection and on one side adjacent to the front of the Post. Thread provided Screw to secure the Post and Extension Bracket (Figure B).

5. ATTACH POST TOP

Attach the Vino Post Top to the Vertical Extension Bracket. Use the provided Drill Bit, drill through Post and Mount above the connection and on one side adjacent to the front of the Post. Thread provided Screw to secure the Post and Extension Bracket (Figure C).

6. MARK THE POST

Lay the connected Post section next to the Post Bottom, interlaced (Figure D). Position the two sections so that the measurement from top to bottom of the base plates equals your ceiling height.

Use a pencil or marker to mark any overlap on the bottom of the connected Post Top Section (from Step 5).

Do not mark/cut from the end with the C-Channel extruding out.

7. CUT THE POST

Using a Metal Cutting Saw, squarely cut off the welded Mounting Bracket from the Post Top section at the mark (Figure E). *Do not use abrasive saws as they may damage the finish.*






Figure F




Figure G

8. CONNECT THE POST

Slide the Post Top Section onto the C-Channel in the Post bottom (Figure F). It may require a Rubber Mallet to connect fully.

9. MARK MOUNTING HOLES

Place the Post in the desired location. Ensure it is plumb with a level and mark the mounting holes on the ceiling, wall, and floor. Set the Post aside.

10. MARK MOUNTING PLATE HOLES

Lay the first Mounting Plate in the desired location on the Post. Mark two (2) mounting hole locations. Mark the holes for the next Plate ensuring a minimum of 3-3/4" vertical clearance from one Plate to the next (Figure G). Use a Level and a Square to ensure Plates are Level. Set the plate to the side.

NOTE: Wine racking can only be installed to one side of the Post when using the Vertical Extension Bracket.

11. Pre-drill MOUNTING HOLES

Using the provided Drill Bit, pre-drill all marked mounting hole locations.

12. ASSEMBLE AND THE PLATES

For Vino Pins

Mounting Plates are sold in two unique widths: one for standard 750ml or Champagne bottles and one for magnum 1.5L bottles.

(Optional) Assemble the Vino Pins and Vino Pins Extensions (Figure H) to reach desired bottle depth (up to 3 bottles deep for 750ml bottles and up to 2 bottles deep, with spacer, for Magnum bottles.

Fasten the Vino Pins to the Mounting Plates using provided M6 Screws (Figure I). Ensure the higher mounting hole in the Mounting Plate points in the direction you want




Figure H




Figure I




Figure J

the bottle neck to face. Fasten the Vino Pins Neck (slimmer bottle impression) piece to the higher of the two holes.

For Vino Rails

Mounting Plates are sold in standard 750ml or Champagne bottles and magnum 1.5L bottles con-






Figure K




Figure L

figurations, each with choice of single, double, or triple bottle width. Thread all Vino Rails to the Mounting Plates using the provided M6 Screws (Figure J, previous page).

NOTE: If installing Vino Rails Magnum wine racks, do not insert supplied Bridge until the entire installation is finished.

13. INSTALL THE PLATES

Attach one (1) assembled Mounting Plate to the Post using two (2) provided Self-Drilling Screws into the pre-drilled holes (Figure K). Repeat the previous step to attach the remaining Mounting Plate assemblies (Figure L).

14. INSTALL THE SYSTEM

Stand the Post Assembly in the desired location and ensure it is plumb both front and back and side-to-side with a level. Mark mounting holes on floor, ceiling, and wall. Set Post aside and pre-drill mounting holes.

Place Post back in place, ensuring it is level, and secure to the ceiling (Figure M) using two (2) of the appropriate fasteners (not provided). Double check the Post is plumb and secure the Post to the floor and wall using two (2) of the appropriate fasteners (not provided) at each location.

If any of the Mounting Plates appear unlevel, loosen one (1) Screw slightly and reposition using a Rubber Mallet and Level (Figure N). Re-tighten the screw.

11. ADD WINE

Only the good stuff.

Problems?

Try using BILT 3D intelligent instructions, visit www.vintageview.com or call 303-504-9463.

Maintenance and Care:

Vino Pins or Rails should be regularly checked for tightness. Should any rack to be found to be loose, tighten by hand until secure. All components of the Vino Series Post System may be




Figure M





Figure N

SCAN FOR BILT 3D INSTRUCTIONS



POWERED BY BILT INTELLIGENT INSTRUCTIONS®

cleaned with a damp cloth and mild dish soap -abrasive pads or steel wool should NOT be used as they will damage the finished surfaces of the parts.



VINTAGEVIEW®
MOVING WINE STORAGE FORWARD